





Tools Required:

Tape Level Drill 1/8" Drill Bit

Optional Tools: Stud Finder

Hardware Included:
(4)Qty - #8 x 1-1/4" Screws
(4)Qty - #8 Nylon Wallboard Anchors
(3)Qty - #8 1-3/8" Stud Screws
(1)Qty - Grid-It Organizer or (3)Qty - Ring Magnets
(4)Qty - #6 x 1" Screws
(6)Qty - Nylon Spacing Washers
(1)Qty - Key Magnet for Locking Pin



Installation Steps:

- 1. Locate a flat and level install location on your wall. We recommend mounting the hinge side holes over a wall stud.
- 2. Align the template with the hinge side holes over wall stud location. Use a level and tape paper template in place.
- 3. Use a 1/8" drill bit and drill all the pilot hole markings (-\(\phi\-\)) on the template.
- 4. Remove template from wall and install included nylon wallboard anchors as needed. Stud mount locations will NOT require anchors and you should screw directly into the wall stud.
- 5. Open the canvas and mount the backplate to the wall using included #8 x 1-1/4" screws in all pre-drilled locations. (Recommend additional help holding canvas to install)
- 6. Remove the rubber cap and use the supplied key magnet on the outside of your canvas to operate the hidden lock. To keep unlocked, place rubber cap back on locking pin.
 - 7. To install Grid-It organizer, place in desired location and attach directly to backplate, through mounting grommets, with supplied #6 screws. To install the rubber coated ring magnets, place in desired location and attach using #6 screws. The nylon washers can be used to bump out the magnets when using a revolver to clear the cylinder. Do not overtighten.
- 8. Adjust the hinges so the canvas does not scrape your wall. If you are having problems with alignment and/or lock, adjust the hinges as needed.

For more information please visit our website, YouTube Channel or contact us directly at info@concealcanvas.com.






















Recommended stud mount location (pre-drill using 1/8" drill bit)

Side

Hinge